

# ENDURE

LABORATORY FURNITURE - CASEWORK



# ENDURE

## The Case for Durability

Steel is the preferred material when looking for strength, durability and chemical resistance. Invincible's line of Inset Steel base units are available in multiple heights including suspended, ADA, sitting and standing with multiple configurations giving you the flexibility to outfit your space in an efficient manner making it user friendly.

Casework is made of mild, cold rolled steel reflecting gauges that meet or exceed industry standards. Front and rear posts provide added strength and durability to back and end panel reinforcement.



Drawer slides are 100 lb. full extension ball bearing allowing for use of entire depth of drawers



Drawers are easy to clean with maximum interior width and depth for more useable space



Units allow for multiple shelf adjustability. Shelf is within 1/2" of inside of door allowing maximum depth.



Leveler access allows height adjustability for uneven floors easily accessible through the cabinet bottom



Toe Kick of formed steel located at each corner on base units



Service access behind units. Unit back access is varied by product family.



Double-sided wall case units



Tempered glass on wall case units with glass



Tall case units standard depth is 22"



Special configurations are no issue. Number plates and label holders as standard ship loose.

## Standard Hardware



Stainless Steel Wire Finger Pull (Standard Default)



Stainless Steel Recessed Pull



Brushed Aluminum Rectangular Finger Pull



Plastic Recessed Pull



Roller Catch



Stainless Steel 5 Knuckle Hinge with Stainless Steel Screws



5-Pin Tumbler Lock with Heavy Duty Cylinder. Security Panel when requested is installed in the factory.



## ALSO AVAILABLE

Fume Hoods  
 Table Frames  
 Lab Accessories  
 Special Products  
 Drawers, Leg Frames  
 Shelving, Standards, Brackets, Lips  
 Umbilicals, Reagent Racks  
 Fillers, Scribes, Misc.



## CASEWORK STANDARD DIMENSIONS

	Width - Dimensions shown are actual	Depth	Height
Base Units	15.375", 17.875", 21.375", 23.875", 30", 35", 42", 47"	22"	24.25" Suspended 28.75" Sitting 31.75" ADA 34.75" Standing
Wall Case Units	15", 18", 21", 24", 30", 35", 42", 47"	14", 16", 18"	24", 30", 36"
Tall Case Units	18", 21", 24", 30", 35", 42", 47"	22"	84"

## POWDER COAT COLOR GUIDE

SEFA 8 and US Green Building Council LEED compliant.

Petal White PCR 01	Shell White PCR 02	Chameleon PCR 03	Platinum PCR 04
Sand PCR05	Khaki PCR06	Dark Khaki PCR07	Dove Gray PCR08
Slate Gray PCR09	Black PCR10	Blue PCR11	Indigo PCR14
Sandstone PCR15	Slight variations in the representation of color may occur due to commercial printing tolerances.		



Invincible's quality steel products are fabricated  
 in Manitowoc, Wisconsin with American labor.  
 Approximately 94% of our component parts  
 (including our steel) are manufactured in the USA.

Invincible Furniture  
[www.invinciblefurniture.com](http://www.invinciblefurniture.com)  
 P 877.682.4601  
 F 920.683.2970  
[sales@invinciblefurniture.com](mailto:sales@invinciblefurniture.com)

©2018 Invincible Furniture  
 Specifications subject to change without notice